

1. HW Version check

Go to Menu / System / HW version and continue with **chapter 2** in case of HW Ver 1.0.0 and with **chapter 3** in case of HW Ver 2.0.0.

2. HW Ver 1.0.0 FW upgrade

All necessary files are in folder HW Ver 1.0.0

1. Remove carefully USB cover from TCX-2 (use a pin or flat knife)
2. Insert battery, turn TCX-2 on and connect it to PC
3. Turn off TCX-2, screen will freeze and your computer will start to install driver for TCX-2, wait for message, it is done. In case driver will not install automatically, please install driver from HW Ver 1.0.0/Driver folder according to your Windows operating system version
4. Run BETSO flash utility from HW Ver 1.0.0/BetsoFlash folder, choose latest FW file from HW Ver 1.0.0 folder (with *.dfu extension) and run the upgrade
5. When upgrade is done, remove battery and insert it again and turn it on

3. HW Ver 2.0.0 FW upgrade

All necessary files are in folder HW Ver 2.0.0

1. Remove carefully USB cover from TCX-2 (use a pin or flat knife)
2. Insert battery, turn TCX-2 on and connect it to PC
3. Turn off TCX-2, screen will freeze and computer will mount new external flash memory unit
4. Copy latest FW file from HW Ver 2.0.0 folder (with *.uf2 extension) to newly mounted external flash memory unit
5. When upgrade is done, remove battery and insert it again and turn it on